

Fieldstand

"Field's Standard"

Model: MHD-01

MOHINORA

INSTRUCTIONS:

1.-For placing a new display, align the screws from the display with the groove that is marked on the case of the timepiece.

2.-Gently press the display into the case keeping the alignment of them.

3.-Now that the display is aligned, unscrew slightly the backcase and press the display firmly.

4.-Once pressed, screw the backcase; the display should be strongly secured to the timepiece.

5.-For removing a display, use the provided key (or a needle) and place it on the groove of the case.

6.-Finally push the key towards the display and at the same time upwards, as if it was a lever, use your fingers to completely remove the display.

CARE OF USE:

1.-Do not open the display.

2.-Dont wear in extreme temperatures or strong magnetic fields.